



Exp. Number	Experiment/Subject LAB 4: MAG/IND	Date
Name Trevor N.	Lab Partner Lauren Lee Phillip	Course & Section No. PH48127: LAB Station 31

Abstract: The goal of this lab is to confirm Faraday's law of induction between coils & magnetic fields.



- 1) Turn on voltage detector
- 2) Pass magnet through coil and observe the voltage



- 1) Place the coil 40 cm away
- 2) Move back & forth 2 cm
- 3) place it close to the magnet, move around
- 4) record the "noise" in the detector

Noise:  $-0.011 \text{ V}$  at 40 cm  
Noise:  $-0.021 \text{ V}$  at on magnet

40-to-center:  $0.396 \text{ V}$   
center-to-40:  $-0.405 \text{ V}$

SS: 40-to:  $0.06177 \text{ Vs}$   
center-to-40:  $-0.08926 \text{ Vs}$

Slower: Max/min Int  
40-to:  $0.167 \text{ V}$   $0.09059 \text{ Vs}$   
center-to-40:  $-0.235 \text{ V}$   $-0.06924 \text{ Vs}$

Max/min Int  
Faster 40-to:  $0.587 \text{ V}$   $0.04096 \text{ Vs}$   
center-to-40:  $-1.274 \text{ V}$   $-0.1269 \text{ Vs}$

Coil over &  $V_p$ :

onto above  
Int:  $0.08035 \text{ Vs}$   $-0.08291 \text{ Vs}$

- 1) Place coil 40 cm away & move it onto the magnet, then move it back

- 2) Record the peak & low

- 3) Integrate the first movement & second movement
- 4) Repeat @ 3 different speeds.

Signature	Date	Signature	Date
-----------	------	-----------	------

Exp. Number	Experiment/Subject	Date
Name	Lab Partner	Course & Section No.



0°

Slow: 0.01035 V<sub>s</sub>, -0.02728 V<sub>s</sub>

Fast: 0.01000 V<sub>s</sub>, -0.02931 V<sub>s</sub>

180°

0.03965 V<sub>s</sub>


-0.05245 V<sub>s</sub>

0.03663 V<sub>s</sub>

-0.05133 V<sub>s</sub>

±28A


A = 1600 × 0.77 cm<sup>2</sup>



Am	
1600	224.05 mV
160	14.97 mV
16	1.73 mV

Measurement of earth's field

≈ 0.65 G



± 0.2

w.r.e:

1.5	-14.25 ± 0.02237 G
2	-10.45 ± 0.02221 G
5	-8.479 ± 0.02699 G
8	-6.866 ± 0.02477 G
12	-5.800 ± 0.03249 G
off	

1) Place coil with axis vertical over the magnet

2) Turn left 90° slowly

3) Turn right 90° slowly

4) Turn left 90° quickly

5) Turn right 90° quickly

6) Integrate the EMF for each movement

7) Now flip 180° 4x very slowly

8) Integrate each movement again.

1) Connect 1600 turn and

2) move and to middle of coil

3) Collect voltage in coil and em

4) Record amplitude of same wave

5) Swap to 160 & 16 turn coils & repeat

1) Record Magnetic field of varying distances for "chance" wire at 1.3A. may 0-magnet

coil	
1	-13.98 ± 0.02814 G
3	-6.427 ± 0.02352 G
5	-5.013 ± 0.0230 G
7	-4.570 ± 0.01714 G
9	-4.458 ± 0.01460 G
11	-4.303 ± 0.01839 G
off	

1	-30.07 ± 0.02397 G
3	-10.20 ± 0.02331 G
5	-6.42 ± 0.01907 G
7	-5.205 ± 0.08188 G
9	-4.814 ± 0.1187 G
11	-4.583 ± 0.1653 G
13	-4.465 ± 0.1772 G
off	-4.267 ± 0.1677 G

Signature	-4.167 ± 0.1845 G	Date	Signature	-4.287 ± 0.1735 G	Date
-----------	-------------------	------	-----------	-------------------	------